



Product: Toce™ Honda CBR1000 T-Slash Exhaust
Year: 2008-2016 **Make:** Honda **Model:** CBR1000RR



Installation Instructions

Remove plastic servo cover from underside of the tail section.

1. Disconnect cable from servo.
2. Remove OEM muffler assembly.
(Make sure the graphite exhaust sleeve comes off with the muffler, if it is stuck on the header; remove it, as it is no longer needed.)
3. Install the Toce mid-pipe with the T-Bolt clamp on the header.
4. Connect muffler until the mounting bracket lines up with the foot peg bracket.
5. Using the factory 8mm bolt and nut, install then tighten T-Bolt clamp.

Shield Installation



1. Install the small bracket behind the right fairing using stock fairing bolt.



2. Install the forked end of the large bracket behind the 8mm exhaust bolt.



3. Install the shield using supplied hardware to the mounting brackets.



4. Once the shield is in position mark and drill a 6mm hole in the small lip on the bottom of the lower fairing.

Thank you for your purchase!

If you need further assistance please check out our Facebook or YouTube channel for video instructions. Or call us directly at the number listed above. We hope you follow us on Instagram, like us on Facebook or leave a review: we would love to hear your feedback.

Parts List

Exhaust Canister Assembly	1
Satin Finish SS Mid-pipe (Optional Black)	1
Shield	1
Shield Mounting Brackets	2

Hardware

O2 Sensor Plug	1
T-Bolt Clamp	1
Springs	2
M5 Button Allen Key Screws (shield)	3
Black Nylon Washers (shield)	3
SS Flat Washers (shield)	3
M5 SS Lock Nuts (shield)	3

ATTENTION: We strongly recommend that this product is installed by a qualified motorcycle mechanic. If you have any doubts as to your ability to perform this installation, please consult with a dealer or repair shop. Be sure to read all instructions before starting