



**Product:** Toce™ Honda CBR600RR Cat-Delete  
**Year:** 2007-2018 **Make:** Honda **Model:** CBR600RR



Parts List	
Link Pipe Assembly	1
Hardware	
Tbolt Clamp	1
M18 Bung Reducer	1
M12 Bung Bolt	1

**ATTENTION:** We strongly recommend that this product is installed by a qualified motorcycle mechanic. If you have any doubts as to your ability to perform this installation, please consult with a dealer or repair shop. Be sure to read all instructions before starting installation. Be sure the motorcycle is secure and stable throughout the entire installation.

### Installation Instructions

1. Measure 3 ½ inches from the weld on the header assembly. As pictured below



2. You need to cut the exhaust straight prior to the bend as you do not want any bends in your cut to optimize airflow.
3. Once cut, clean the rough edges of the pipe inside and out with a file or dremel
4. Once completed, slide the provided clamp over the mid-pipe, and slide the link pipe over the header.



5. Attach your Toce T-Slash Exhaust System, align to ensure everything is lined up accordingly, and tighten all clamps from the header assembly back. You're finished!



### Thank you for your purchase!

If you need further assistance please check out our Facebook or YouTube channel for video instructions. Or call us directly at the number listed above. We hope you follow us on Instagram, like us on Facebook or leave a review: [w](#)

### Warranty

Toce Brothers Performance products are intended for closed course competition and show use only, and therefore are sold "as is" without warranty. Toce Brothers Performance, LLC specifically disclaims any warranties of merchantability or fitness for a particular purpose and disclaims all responsibility for consequential and incidental damages or any other losses arising from the use of these products.